PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

Replacement parts shown may be superseded by the availability of newly introduced replacements. Have your local distributor check Sams COUNTER FACTS* for the most up-to-date replacement.

CRYSTALS

ITEM No.	CRYSTAL FREQUENCY IN MHz	MFGR. PART No.	CTS KNIGHTS PART No.	CHANNEL
X801	11.0500	YEXLHC18U016	CA90W11050	Rec Osc
X901	10.5950	YEXLHC18U017	CB75W10595	Xmit osc

ITEM No.	CRYSTAL FREQUENCY IN MHz	MFGR. PART No.	CTS KNIGHTS PART No.	CHANNEL
X902	10.2400	YEXLHC18U015		PLL

MISCELLANEOUS

ITEM No.	PART NAME	PART No.	NOTES	
CF151 CF152 CF801 CF901 CF902 M80 M901 SW51 SW52 SW701 SW802 SW803 SW904 SW905	Filter Filter Filter Filter Filter Tuner Meter Switch Switch Switch Switch Switch Switch Switch Switch Switch	YEINO9N5004 YEINO9N5004 YEIO07P2005A EFCS27MT1 YEINO9N50040 YEAU01056 YEAV01003 YEAS07042 YEAS07042 YEAS09061 YEAS09056 YEAS10003	10.7MHz 10.7MHz 455kHz 27MHz 47MHz 27MHz AM/FM S/RF DX/LDCAL AM/FM Power (Part of Volume Control) Delta Tune (Part of Squelch Control) CB/Radio Monitor CB Channel Selector	

CABINETS & CABINET PARTS (When ordering specify model, chassis & color)

ITEM	PART No
Escutcheon Assembly Cover, Top & Bottom Panel, Front Panel, Rear Dial Pointer Knob, CB Channel	YEFC02378 YEFA03215 YEFA07019 YEFA08019 YEFH01145 YEFE17048


ITEM	PART No.
Knob, Squelch	YEFE07077
Knob, Delta Tune	YEFE08071
Knob, AM-FM	YEFE17047
Knob, Tuning & Volume Control	YEFE07063
Knob, Tone & Balance	YEFE08057
Push Button, CB/Radio-DX/LOCAL	YEFE10189

WIRING DATA

General-use Hook-up Wire	
Shielded Antenna Lead	Use BELDEN No. 8214 Lowest-loss (RG-8/U Type) 8237 Low-loss (RG-8/U)
Coiled Microphone Cable	9240 (Solid) Miniature (RG-58/U) 8259 (Stranded) Miniature (RG-58A/U) Use BELDEN No. 8497 3-Conductor (1 shielded for Press-to-Talk) Neoprene
Bonding Strap	Use BELDEN No. 8661 (3/8 inch)

DIAL CORD STRINGING

TOP VIEW



FRONT



PHOTOFACT® with

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna



MODEL Washington

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

ALIGNMENT INSTRUCTIONS

SYNTHESIZER ALIGNMENT

TEST	EQUIPMENT		TR	ANSCEIVER	ADJUST	REMARKS
Input of RF	VTVM to TP6.		Ch. 1, Clarifi	AM ler - Mid Range	L24	Adjust for maximum.
Input of DC	meter to TP7,		Ch. 1,		L17	Adjust for 2.0 volts.
Input of RF	VTVM to TP8.		Ch. 19		L16	Adjust for maximum.
Input of fre	equency counter	to TP8.	Ch. 19		CT6	Adjust for 34.9850MHz + 20Hz.
Input of fre	quency counter	to TP8.	Ch. 19,	USB	CT4	Adjust for 34.9875MHz + 20Hz.
Input of fre	quency counter	to TP8.	Ch. 19,	LSB	CT5	Adjust for 34.9825MHz +20Hz.
Input of fre	quency counter	to TP8.	Ch. 19,	LSB, Xmit	VR9	Adjust for 34,9825MHz <u>+</u> 20Hz,
Input of fre	quency counter	to TP9.	Ch. 19,	USB	СТ2	Adjust for 7.8025MHz +5Hz -0Hz.
input of fre	quency counter	to TP9.	Ch. 19,	LSB	CT3	Adjust for 7.7975 +0Hz -5

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil. Adjust volume control to obtain a suitable indication.

SSB

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .0luF to antenna jack. 27.186MHz, no modulation. Output .25uV.	Ch. 19, USB RF Gain - Max Clarifier - Mid Range Volume - Max.	L8, L7, L6, L5, L4, L3	Adjust for maximum output.
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output .25uV.	Ch. 19	CT1	Adjust for .5 watts audio.

RECEIVER ALIGN: MENT

Connect an AC VTVM or AF wattmeter across speaker voice coil. Adjust volume control to obtain a suitable indication.

AM

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .0luF to antenna jack. 23.5MHz, no modulation. Output 200uV. Input of RF VTVM to TP5.	Ch. 19, AM RF Gain - Max. NB-On	L1, L2	Adjust for maximum.

RECEIVER ADJUSTMENTS

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output 250uV.	Ch. 19, USB RF Gain - Max Volume - Max	VR2	RF GAIN RANGE Adjust VR2 for .5 volts audio.
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output 100uV.	Ch. 19	VR1	S METER Adjust for 9 on S scale of meter.
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output 500uV.	Ch. 19	VR3	SQUELCH RANGE Set squelch control VR40 fully clockwise. Adjust VR3 so that squelch just breaks.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% No modulation.	Ch. 19	VR5	AM BALANCE Adjust VR5 for .5 watts audio.

TRANSMITTER ALIGNMENT

Output .5uV.

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.

NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.

See Page 4 for channel frequencies.

SSB

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of 2-tone generator to Mike input. 500Hz and 2400Hz at .5 volts.	Ch. 19,USB, Mike Gain - Max.	L39, L37, L32, L30	Adjust for maximum.
Output of 2-tone generator to Mike input. 599Hz and 2400Hz at .5 volts.	Ch. 19, LSB	CT7	Adjust CT7 for 11.5 watts.

TRANSMITTER ADJUSTMENTS

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.

NOTE: Be sure to check transmit frequency and power on all active channels after alignment of

transmitter.

See Page 4 for channel frequencies.

AM

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Input of spectrum analyzer to antenna jack.	Ch. 19	L27	Adjust for MINIMUM at 54MHz.

TRANSMITTER ADJUSTMENTS

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.


NOTE: Be sure to check transmit frequency and power on all active channels after adjustment of


transmitter.
See Page 4 for channel frequencies


TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS		
Input of DC meter to TP10.	Ch. 19	RT301	VOLT REG Voltage should not vary when keying transmitter.		
DC current meter to TP3 and TP4.	Ch. 19, USB	VR15	BIAS Adjust VR15 for 40mA +10mA		
DC current meter to TP1 and TP2.	Ch. 19, USB	VR16	BIAS Adjust VR16 for 70mA +10mA		
No Modulation	Ch. 19, USB	VR4	BALANCE Adjust for MINIMUM RF.		

TRANSMITTER ADJUSTMENTS (Continued)

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
No Modulation	Ch. 19, AM	VR8	AM REG Adjust VR8 for 3.8 watts.
No Modulation	Ch. 19, AM	VR12	RF PANEL METER Adjust VR12 for 3.8 watts on on RF scale of meter.
Modulation meter to antenna jack.	Ch. 19, AM. AMC-MAX	VR7	AM AMC Adjust signal for 50% modulation. Increase signal 630 times. Adjust VR7 for 95% modulation.







PARTS LIST AND DESCRIPTION


(When ordering parts, state Model, Part Number, and Description.)


WIRING DATA

General-use Hook-up Wire	Use BELDEN No. 8530 (Solid) Available in 13 Colors
	8524 (Stranded) Available in 13 Colors
Power Cord. 2-Wire	Use BELDEN No. 17106 (Plastic) -6 feet
	17109 (Plastic) -9 feet
Shielded Antenna Lead	Use BELDEN No. 8214 Lowest-loss (RG-8/U Type)
	8237 Low-loss (RG-8/U)
	8240 (Solid) Mintature (RG-58/U)
	8259 (Stranded) Miniature (RG-58A/U)
Coiled Microphone Cable	Use BELDEN No. 8497 3-Conductor (1 shielded for Press-to-Talk) Neoprene

SEMICONDUCTORS (Select replacement transistor for best results)

TYPE WEST			REPLACEMENT DATA							
No.	TYPE No.	MFGR. PART No.	GENERAL ELECTRIC PART No.	IR WORKMAN PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No
1	152473	2000-317 2000-317 2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
	152473	2000-317	GE-300 GE-300	D200 D200	PTC214 PTC214	HEPRO602 HEPRO602	RE 52 RE 52	SK3100 SK3100	RT-218 RT-218	ECG519 ECG519
	1S2473 1S2473	2000-317	GE-300	D200	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519
	152473	2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
	152473	2000-317	GE-300	D200	PTC214	HEPR0602	RF 52	SK3100	RT-218	ECG519
	152473	2000-317	GE-300	D200	PTC214	HEPR0602	RE 52 RE 52	SK3100 SK3100	RT-218	ECG519
	152473	2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519 ECG519
)	152473 1N60P	2000-317	GE-300	D200 1N60	PTC214 PTC206	HEPRO602 HEPR9135	RE 52	SK3100 SK3088	RT-218 RT-263	ECG109
10 11	1N60P	2000-318	1N60 1N60	1860	PTC206	HEPRO135	RF 47	SK3088	RT-263	ECG109
i2	152473	2000-318 2000-318 2000-317	GE-300	1N60 D200	PTC206 PTC214	HEPR9135 HEPR0602	RE 47 RE 47 RE 52	SK3100	RT-218	ECG519
13	152473	2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100 SK3100	RT-218	ECG519 ECG519
14		2000-317	GE-300	D200 1N60	PTC214 PTC206	HEPRO602 HEPR9135	RE 52 RE 47	SK3100	RT-218 RT-263	ECG109
15	1N60P 1N60P	2000-318 2000-318	1N60 1N60	1060	PTC206	HEPR9135	DE AT	SK3088	RT-263	ECG109
7	152473	2000-317	GE-300	D200	PTC214	HEPR0602	RE 52 RE 52 RE 52 RE 52	SK3100	RT-218	ECG519
18 l	152473	2000-317	GF-300	D200	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519
19	1S2473 1S2473	2000-317	GE-300 GE-300	0200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519 ECG519
20	152473	2000-317	GE=300	D200	PTC214	HEPRO602 HEPRO602	RE 52	SK3100 SK3100	RT-218 RT-218	ECG519
21	1S2473 1S2473	2000-317 2000-317	GE-300 GE-300	D200 D200	PTC214	HEPROSO2	RE 52	SK3100	RT-218	ECG519
3	152473	2000-317	GE-300 GE-300	D200	PTC214 PTC214 PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
4	C7002	2000-327	GEZD-9.1	Z1209	ZB9.1A	HEPZO412	RE 114	SK3060	RT-240	ECG139
25	BZ075	2000-324	GEZD-7.5 GEZD-5.1		ZB7.5B		RE 111		RT-239 RT-235	ECG138
6	WZ050	2000-321	GE-504A	5A4D	PTC201	HEPRO052	RE 49	SK3030	RT-213	ECG116
27	SR1K2 CZ092	2000-320	GEZD-9.1	Z1209	ZB9.1A	HEPZO412	RE 114	SK3060 SK3100	RT-240	ECG139 ECG519
P	152473	2000-317	GE-300	D200	PTC214	HEPR0602	RE 52		RT-240 RT-218	ECG519
30 31	152473 152473	2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
31	WZ061	2000-329 2000-322 2000-317	GEZD-6.2		ZB6, 2B		RE 109 RE 109		RT-237 RT-237	ECG137 ECG137
33	WZ061 1S2473	2000-322	GEZD-6.2	D200	ZB6,2B	HEPRO602	RE 52	SK3100	RT-218	ECG519
34	152473	2000-317	GE-300 GE-300	D200	PTC214 PTC214	HEPRO602 HEPRO602	RE 52 RE 52	SK3100	RT-218	ECG519
35	152473	2000-317	GE-300	D200	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519
36	152473	2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100 SK3100	RT-218 RT-218 RT-218	ECG519 ECG519
37	152473	2000-317	GE-300	D200 D200	PTC214 PTC214	HEPRO602 HEPRO602	RE 52 RE 52	SK3100	RT-218	ECG519
38 39	1S2473 1S2473	2000-317	GE-300 GE-300	D200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
40	152473	2000-317	GE-300	D200	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
41	1S2687D	2000-323	GE-90	D201		HEPR2503	RE 195	SK3126	RT-262	
43	1S2687D	2000-323	GE-90	D201	700 11	HEPR2503	RE 195	SK3126	RT-262 RT-240	500130
144	CZ092	2000-327	GEZD-9.1 GE-90	Z1209 D201	ZB9.1A	HEPZ0412 HEPR2503	RE 114 RE 195	SK3060 SK3126	RT-262	ECG139
45 46	1S2687D 1S2473	2000-323	GE-300	D200	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519
47	152473	2000-317	GE-300	D200	PTC214 PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG519
50	1S2473 1N60P	2000-318	1N60	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109
51	KB162W	2000-331			PTC301					
52 53	KB162W 1S2473	2000-331 2000-331 2000-317	GE-300	D200	PTC301 PTC214 PTC201	HEPR0602	RE 52	SK3100	RT-218	ECG519
54	SR1K2	2000-320	GE-504A	5A4D	PTC201	HEPRO052	RE 49	SK3030	RT-213	ECG116
56	152473	2000-317	GE-300	D200	PICZ14	HEPRO602	RE 52	SK3100	RT-218	ECG519
57	152473	2000-317	GE-300 GE-300	D200 D200	PTC214 PTC214	HEPRO602 HEPRO602	RE 52 RE 52	SK3100 SK3100	RT-218 RT-218	ECG519 ECG519
58 59	1S2473 1N60P	2000-317 2000-318	1N60	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109
60	152473	2000-317	GE-300	D200	PTC214	HEPR0602	RE 52	SK3100	RT-263 RT-218	ECG519
61	152473	2000-217	GE-300	D200	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519
301	WZ061 BZ162	2000-328	GEZD-6.2		ZB6.2B		RE 109 RE 122		RT-237 RT-246	ECG137 ECG5075
302 406	S5VB10	2000-328 2000-326 2000-330	GEZD-16		ZB16B		WE 122		240	1000073
ETI	35K45B	2000-102	GE-FET-4	WEP905	PTC181 PTC181	HEPF2004	RE 199	SK3050	RT-181	ECG222
	3SK45 (1)		GE-FET-4	WEP905		HEPF2004	RE 199	SK3050	RT-181	ECG222
ET2	JF1033G	0000 300 401	GE-FET-2	FE-100	PTC161	HEPF0021	RE 45	SK3116	RT-175 RT-175	ECG312
	JF1033	2000-105 (1)	GE-FET-2 GE-FET-2	FE-100 FE-100	PTC161 PTC161	HEPF0021 HEPF0021	RE 45	SK3116 SK3116	RT-175	ECG312 ECG312
	2NJ233B(1 2SK19 (1)		GE-FET-2	FE-100	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312
	2SK33 (1)		GE-FET-2	FE-100	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312
ET3	2SK68	lane in the	GE-FET-1	FE-100	PTC151	HEPF0010	RE 46	SK3112	RT-176	ECG133
	25K68A,M	2000-104 (1)	GE-FET-1	FE-100	PTC151	HEPF0010	RE 46 RE 46	SK3112 SK3112	RT-176 RT-176	ECG133 ECG133
ET4	2SK30A(1)		GE-FET-1 GE-FET-4	FE-100	PTC151 PTC181	HEPF0010 HEPF2004	RE 199	SK3050	RT-181	ECG222
ET4	3SK45-B-0	92000-103 (1)	GE-FET-4	WEP905 WEP905	PTC181	HEPF2004	RE 199	SK3050	RT-181	ECG222
	3N201 (1)		GE-FET-4	WEP905	PTC181	HEPF2004	RE 199	SK3050	RT-181	ECG222
	3SK45 (1)		GE-FET-4	WEP905	PTC181	HEPF2004	RE 199	SK3050	RT-181	ECG222
	35K40 (1)		GE-FET-4	WEP905	PTC181	HEPF2004	RE 199 RE 199	SK3050 SK3050	RT=181	ECG222
-	35K41 (1)		GE-FET-4	WEP905	PTC181	HEPF2004 HEPF0010	RE 46	SK3112	RT-176	ECG222 ECG133
ET5	25K68		GE-FET-1	FE-100	PTC151	HEPF0010	RE 46	SK3112	RT-176	ECG133





PARTS LIST AND (When ordering parts, state

CEAN CONDUCT

EMICONDUCT				
No.	TYPE No.	MF PART		
FET6	2SK30A(1) JF1033G			
2.10	JF1033	2000-1		
	2NJ233B(1) 2SK19 (1) 2SK33 (1)			
FET7	3SK45B 3SK45 (1)	2000-1		
IC1 IC2	UPC577M	2000-0		
106	MC1496A UC1496A LM1496N(1)	2000-0		
IC3 IC4	UPC592H2 UPC1156H	2000-0		
IC5	UHICO05 UPC78L05	2000-0		
IC6 IC7	UPD858	2000-0		
TOI	UPD858C KM858C(1)	2000-0		
TRI	2SC945AP 2SC945(1)	2000-2		
TR2	2SA733P 2SA733(1)	2000-2		
TR3	2SC945AP 2SC945(1)	2000-2		
TR4	2SC945AP 2SC945(1)	2000-		
TR5	2SC1730L 2SC1730(1	2000-		
TR6	2SC1675L 2SC1675(1	2000-		
TR7	2SC1675L 2SC1675L 2SC1675L 2SC1675L 2SC1675[1	2000-		
TR8	2SC1675L 2SC1675(1	2000-		
TR9	2SC1675L 2SC1675(1	2000-		
TRIO	2SC1675L 2SC1675(1	2000-		
TR11	25C945AP 25C945(1)	2000-		
TR12	25C945AP 25C945AP 25C945(1)	2000-		
TR13	2SC945AP 2SC945(1)	2000-		
TR14	2SC945AP	2000-		
TR15	2SC945(1) 2SC945AP	2000-		
TRIG	2SC945(1) 2SC945AP	2000-		
TR17	2SC945 2SA733P	2000-		
TRIB	2SA733(1 2SC945AP	2000-		
TR19	2SC945(1 2SA733P	2000-		
TR20	2SA733(1 2SC945AP	5000-		
TR21	2SC945AP	2000-		
TRZZ	2SC945(1 2SC945AP	2000-		
TR23	2SC945(1 2SC945AP	2000-		
TR24	2SC945(1 2SC1419B			
TR25	2SC1419(2SC1419B	2000		
TR26	2SC14198 2SC14196 2SC14198 2SC14196 2SC945AP	2000		
TR27	2SC1675L	2000		
TR28	2SC16750 2SC16750	2000		
TR29	2SC1675	11		
1	2SC945AF	2000		
	2SC945AF (1) 2SC945(1 2SC828(3		
-	2SC1740(14		
	2SC458(1 2SC900(1) [
TR30	2SC372(1 2SC1675L	2000		
TR31	2SC1675L 2SC1675L 2SC1675L 2SC1675L	2000		
TR32	25C945A1	2000		
	2SC945(1 2SC945AI	2000		
TR33				
1	25C945(1 25C1675l	200G		
TR34	2SC16751 2SC16751 2SC458C	200G		

@ Howard W. Sams & Co., Inc. 1977